

HSD Reflex Post Accessories

Accessories for use with Chain



STOCK CODE: HSDRPADAPT194

Description: Adaptor for Reflex Post

This adaptor is required for Reflex Posts to attach any of the following accessories



STOCK CODE: HSDRPEYECC

Description: Eyelet for chain on Reflex Post.

Used to thread chain through the top of Reflex posts.
(NB Must use adaptor HSDRPADAPT194 in conjunction with the eyelet.)



STOCK CODE: HSDPCC.175A

Description: Plastic Chain Clip/Split Link for Reflex Post (175A)

Used to join chain lengths or to split chain for easy opening/closing.

Adaptor Attachments



STOCK CODES:

- HSDPRS300120SS** Round Plastic Sign 300mm. Single sided RA1 Or RA2
- HSDPRS300120DS** Round Plastic Sign 300mm. double sided RA1 Or RA2
- HSDRPRECS** Rectangular Sign Double Sided for Reflex Post RA1 or RA2
- HSDRPRECS** Rectangular Sign Double Sided for Reflex Post RA1 or RA2
- HSDSPL11816R** Solar Power Flashing Light Red for Reflex Post
- HSDSPL11825A** Solar Power Flashing Light Amber for Reflex Post

Knocktopher, Co. Kilkenny, R95 TW83

T: (056) 7768702 | F: (056) 7768854
email: sales@hsd.ie | www.hsd.ie